




# COOKTOP PARTS

For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)

30" Slide-In  
DESIGNER STYLE  
Gas Range




Illus. No.	Part No.	DESCRIPTION
1	LIT9753052	Literature Parts
	LIT9753051	Installation Instructions
	LIT9753053	Use & Care Guide
	LIT9753055	Tech Sheet
	LIT9753055	Wiring Diagram
	LIT9753426	Template, Anti-Tip
	LIT9753502	Instructions (LP Conversion)
	LIT3191638	Safer Cooking Tips
	LIT9781877	Service Instr.
	LIT9753268	Back Trim Instr.
2		Cooktop, Gas
	9781890GW	White
	9781890GB	Black
	9781890GT	Almond
	9781890GC	Biscuit
3	9752889	Trim, Rear
5		Cap, Vent
	9753772GW	White
	9753772GB	Black
6	9752890	Trim, Side
7		Cap, Burner
		Large
	3191905	Grey
	3191904	Black
		Small
	3191899	Grey
	3191898	Black
11	9780265	Screw, 10-16 x 3/8
12	9752974	Support, Cooktop
13	9751629	Bracket, Pivot
16		Grate, Burner
	8053455	Cumberland Grey
	8053456	Black
17	9751984	Bimetal, Fan
18	341196	Thermostat, SPST
20	9751644	Screw, 10-24 x 1/2
	9781235	Speed Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS


For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	9752897PB	Panel, Control Black
	9752897PW	White
	9752897PT	Almond
	9752897PC	Biscuit
2		Glass-Console
	9752901CB	Black
	9752901CW	White
	9752901CT	Almond
	9752901CC	Biscuit
4		End Cap Left
	9781889FB	Black
	9781889FW	White
	9781889FT	Almond
	9781889FC	Biscuit
		Right
	9781888FB	Black
	9781888FW	White
	9781888FT	Almond
	9781888FC	Biscuit
5	9753504	Gasket, Cover
6	9752955	Cover, Control
7	9752906	Clip, Glass (2)
8		Knobs, Control (4)
	3187767	Black
	3187766	White
	3187768	Almond
	9753990FC	Biscuit
9	9753503	Label-WPSI Control
15	9753639	Control, Range
16		Knob, Timer (18)
	9781954FB	Black
	9781954FW	White
	9781954FT	Almond
	9781954FC	Biscuit
34	9780265	Screw, 10-16 x 3/8
35	9780273	Screw, 10-16 x 3/4

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)**




3

# BROILER & OVEN BURNER PARTS

For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1	9752737	Shield, Oven (2)
2	9752738	Flame Shield, Bake
3	9752980	Shield, Flame
4	9751367	Burner, Bake
5	9753108	Ignitor, Broiler Burner
6	9753108	Ignitor, Oven Burner
7	9751643	Screw, 10-24x3/8
8	9752736GM	Pan, Oven Bottom
9	9752985	Tubing, Broil
10	9752698	Valve, Regulator Assembly
11	776593	Screw, 1/4-20x1/2
12	9781015	Tubing, Valve
13	9752734	Pan Support, Bake
14	9751600	Bracket, Bake
15	9753409	Deflector, Broil
16	9752981	Burner, Broil
18	9751644	Screw, 10-24 x 1/2
19	9752984	Fitting, Broiler
20	9780265	Screw, 10-16 x 3/8
21	9781509	Screw, 8-32 x 3/8
22	9751643	Screw, #10 x 3/8



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND DRAWER PARTS

For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND DRAWER PARTS


For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9781592	Baffle, Glass	6		Vent, Door	16	9781587	Seal, Glass
2		Trim, Door-Left	9753498GW		White	18	9754006	Insulation
	9782003PW	White	9753498GB		Black	19	9781600GM	Liner, Door
	9782003PB	Black	9753498GT		Almond	20	9780583	Drawer & Roller
	9782003PT	Almond	9753498GC		Biscuit	21	9750169	Bracket, Drawer
	9782003PC	Biscuit	9781490		Seal, Door	22	9780272	Screw (4) 10 x 1/2
3		Trim, Door-Right			Vent Side	24		Front, Drawer
	9782004PW	White	9781659		Gasket, Door Vent	9750168PW		White
	9782004PB	Black	8		Handle, Door	9750168PB		Black
	9782004PT	Almond	9752701PW		White	9750168PT		Almond
	9782004PC	Biscuit	9752701PB		Black	9750168PC		Biscuit
4		Trim, Door Bottom	9752701PT		Almond	25	423713	Support, Roller
	9781209PW	White	9752701PC		Biscuit	27	9750676	Retainer, Panel
	9781209PB	Black	9	9781449	Gasket, Door Glass	90296		Clip
	9781209PT	Almond	10	9750234	Hinge, Door R or L	28	9781502	Retainer, Glass
	9781209PC	Biscuit		90296	Clip	29	9780265	Screw, 10-16 x 3/8
5		Glass, Door	12	9781602	Frame, Window	30	9750693	Channel, Heat
	9781694PW	White	13	9781586	Shield Door	9754005		Insulation, Drawer Rear
	9781694PB	Black	14	9780771	Bumper, Rubber			
	9781694PT	Almond	15	9781593	Glass, Door (2)			
	9781694PC	Biscuit						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN CHASSIS PARTS

For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN CHASSIS PARTS

For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1	9753300	Vent, Burner Box
2	9750514GM	Chassis, Front
3	8935	Bulb, Oven
4	9781050	Socket, Light
5	9753011GM	Oven Liner
6	3191649	Gasket Oven
7		Oven, Side L or R
	9781907PW	White
	9781907PB	Black
	9781907PT	Almond
	9781907PC	Biscuit
8	9780664	Shield, Insulation
9	9751789	Fan Duct, Side
10	8053421	Spark Module
11	9752975	Burner Box
12	9752735	Retainer, Insulation
13	9751653	Duct, Top
	9780265	Screw, (2)
14	9751060	Support, Fan
15	9750223	Drawer Rail, Left 10 x 3/8
	9750224	Drawer Rail, Right
16	9751020	Motor, Fan
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9750149	Hinge, Receiver
20	9781904	Support Rail, Pan
21	9781025	Shield, Drawer
22	9751641	Plate, Reflectance
23	420101GM	Pan, Broiler
24	9750498	Rack, Standard (2)
25	9780269	Screw
26	8053344	Sensor, Oven
27	9781049	Lens, Light
28	3184533	Gasket, Lens
29	9781580	Door Switch
30	420104GM	Grill, Broiler
31	9752978	Vent, Burner Box
32	9751644	Screw, 10-24 x 1/2
33	9753067	Extension, Vent Box
34	9754004	Insulation, Wrap
35	9780265	Screw, 10-16 x 3/8
36	9780275	Screw, #8 x 3/8
37	9751808	Screw, #8 x 1
38	9751871	Screw
39	9781509	Screw, 8-32 x 3/8
40	9754011	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# REAR CHASSIS PARTS

For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9751051	Back Panel, Chassis	9	422222	Screw	17	9752462	Single Position Device (Not Serviced)
3	9751353	Panel, Rear Cover	10	424238	Washer	20	98884	Screw
5	9750526	Bracket, Lock	12	9750965	Switch, Interloc	21	340184	Screw 10-16 x 11/2
6	9751500	Bracket, Regulator-Valve	13	9750887	Screw, (2)	22	423247	Screw
7	9752404	Oven Lock Assembly (Includes Key #17)	14	9750888	Nut (2)	24	9780265	Screw, #10 x 3/8
8	9752409	Solenoid	15	9750523	Rod, Lock			
			16	258076	Block, Terminal			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MISCELLANEOUS PARTS

For Models: GW395LEGQ3, GW395LEGB3, GW395LEGZ3, GW395LEGT  
(Designer White) (Designer Black) (Designer Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b><u>SPLICING WIRES--25FT. LENGTH</u></b>			<b><u>PAINT, PRESSURIZED SPRAY (12 oz.)</u></b>			<b><u>Miscellaneous</u></b>		
	242828	Wire, Black 12 Ga. 150°c		350930	White		9753267PB	Trim, Back Cover Black
	242820	Wire, Black 14 Ga. 150°c		350956	Almond		9753267PW	White
	242821	Wire, Blue 14 Ga. 150°c		261888	New Avocado		9753267PT	Almond
	242822	Wire, Brown 14 Ga. 150°c		261886	Coffee		9753267PC	Biscuit
	242830	Wire, Brown 14 Ga. 200°c		261890	Harvest Gold	<b><u>ACCESSORIES</u></b>		
	242823	Wire, Green 14 Ga. 150°c		285006	Superior Black		241430	Foil, Aluminum Oven (18" X 25')
	242824	Wire, Orange 14 Ga. 150°c		206922	Primer (White)	<b><u>CONVERSION KIT</u></b>		
	242829	Wire, Red 12 Ga. 150°c		4392901	Biscuit		9753054	Gas Conversion Kit (LP)
	242825	Wire, Red 14 Ga. 150°c	<b><u>PAINT, BULK (1 qt.)</u></b>				9752717	(Natural)
	242831	Wire, Red 14 Ga. 200°c		799344	White (Uncut)	<b><u>LUBRICANT</u></b>		
	242826	Wire, White 14 Ga. 150°c	<b><u>REFINISHING MATERIAL</u></b>				261582	Grease
	242827	Wire, Yellow 14 Ga. 150°c		799832	Kit, Porcelain Repair (White)	<b><u>ANTI-TIP KIT</u></b>		
	242832	Wire, Yellow 14 Ga. 200°c		242756	Touch-Up Self-Clean (1/2 Pt.)		9751745	Anti-Tip Kit
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>			<b><u>INSULATION</u></b>			<b><u>WIRING HARNESS PARTS</u></b>		
	72017	White		9751164	Insulation, Wrap		9753758	Harness, Wire (Main Harness)
	72107	Almond		9750221	Insulation, Rear		9753101	Harness, Wire (Neutral Gas)
	72109	New Avocado		9751323	Insulation, Bottom		9752769	Harness, Wire (Dual Cooktop)
	72108	Coffee	<b><u>CLEANER, COOKTOP</u></b>				9750744	Harness, Wire (Oven Door)
	72110	Harvest Gold		3184477	Glass Cleaner		9753158	Harness, Wire (Spark Module)
	**511873	White Porcelain (2 Oz.)		3183488	Scraper		98997	Clip
	4392899	Biscuit					20082084	Tie, Wire
* * <b>NOTE:</b> The spray paint is Porcelain; All Other Panels are Painted Surfaces.							9781055	Cord, Power
							9751868	Grommet Harness(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST